




# BONDING




3. Select bonding system and apply to prep.




4. Dispense NX3 cement (light-cure or dual-cure) directly into veneer.



5. Seat veneer. Spot cure for several seconds. Remove mylar strip. Clean excess cement from margins.



6. Light cure all surfaces for 20 seconds each. \*\*



7. Finish and polish.




**NX3's optimal  
handling allows  
easy cleanup  
in gel state.**

# CERAMIC CROWNS




1. Apply try-in gel to restoration and seat. Check color and fit. Remove restoration.



2. Thoroughly wash out try-in gel. Air dry. Shield silane primer from ambient light and apply.




# BONDING




3. Select bonding system and apply to prep.




4. Dispense NX3 cement (light-cure or dual-cure) onto restoration or prep.



5. Seat restoration onto prep, allowing cement to flow from all sides. Tack cure (1-2 seconds) to facilitate cleanup. Remove excess cement.



6. Light cure all surfaces for 20 seconds each. \*\*




7. Finish and polish.




# METAL-BASED CROWNS

Due to its proprietary *amine-free* initiator system, NX3 dual-cure cement exhibits superior compatibility with both total-etch and self-etch adhesives in dark-cure situations where there is limited light accessibility.


NX3 simplifies your procedure – it is not necessary to use a primer/adhesive on the metal surface.



# BONDING




3. Select bonding system and apply to prep.




4. Dispense NX3 dual-cure cement onto restoration or prep.



5. Seat restoration onto prep, allowing cement to flow from all sides. Tack cure (1-2 seconds) to facilitate cleanup. Remove excess cement.




6. Light cure all surfaces for 20 seconds each. \*\*




7. Finish and polish.



# BONDING




1. Select bonding system and apply to prep.



2. Sandblast & clean inside surface of restoration. Dispense NX3 dual-cure cement onto restoration or prep.



3. Seat restoration onto prep, allowing cement to flow from all sides. Tack cure (1-2 seconds) to facilitate cleanup.



4. Remove excess cement. Remove excess cement. Light cure all surfaces for 20 seconds each. \*\*



5. Finish and polish.

